Smart SOT Cart



Item #	Parts List	Qty
1	Cart Frame	1
2	Wheels	2
3	Lock Rings	2
4	Mesh Storage Bag	1

Assembly:

- 1 No assembly required for frame.
- 1. Slide on wheels with air valves facing out.
- 2. Install lock rings in hole next to wheel and flip the lock ring over the end of the frame to secure the wheels in place.

Using the Smart SOT Cart:

- 1. Adjust cart post to match width of Scupper holes in boat making sure to tighten both screws securing the post.
- 2. Lift boat off the ground from one end and insert cart post into Scupper holes in boat then let the boat down. Cart can be mounted in center or one of the ends
- 3. Boat is ready to be pulled to the destination.
- 4. Max weight is 150 lbs, this includes boat and all gear in boat. Do not overload cart.

Care:

- 1. Tires should be inflated to **25 psi**, use 20 psi if using in sand or soft ground.
- 2. Rinse cart after each use to clean off sand, salt and mud.

Warnings:

Wheels

Be careful when inflating tires, over inflation can result in shattering of plastic rim and could result in severe injury. *Strongly suggest using a hand pump to watch the pressure when filling tires with air.*

Straps

When putting straps around the boat make sure the non-marring buckle protection fabric is under the buckle before pulling strap tight. Do not pull straps too tight when connecting the cart to the boat; this could result in damage to the boat.

This cart is not intended to be pulled behind a motorized vehicle.

Guarantee

All Suspenz products are guaranteed for one year for materials and workmanship. The guarantee is affective to the original owner and if the product was cared for and used in the manner is was intended. Contact the retailer you bought the product from or Suspenz direct.

www.suspenz.com



Suspenz Inc. 8725 Roswell Road #0-220 Atlanta GA 30350 770-518-0045